



thermo**PLY**[®]
structural sheathing by **OX**

GREEN, RED, BLUE, & AMG

Damage Repair Guidelines

Damage to Panel Description	Repair Guideline
Facer Delaminations	Small Areas: Apply Ox Seam Tape Large Areas: Liquid House Wrap (StoGuard or equal)
Tears or holes in Thermo-Ply less than 1" in length or diameter (non-structural)	Use 4" Arctic Flash Flashing Tape
Tears or holes up to 3" in length or diameter.	Back with 2x6 blocking (min), fasten to blocking, and apply Arctic Flash Flashing Tape
Tears or holes greater than 3" in length or diameter	Replace Panel

**These guidelines should be used with good judgement to ensure sheathing maintains intended structural, moisture, and air barrier requirements.*

OX Engineered Products
22260 Haggerty Road Suit 365
Northville, MI 48167
p. 248.289.9950
f. 248.289.9955
oxep.com